



SP-C085 Overview (Unit: mm)


Front View




Rear View




Side View



Top View




Bottom View




SP-C105 Overview


Front View




Rear View



Side View



Top View




Bottom View




Wall Mount Cut-Out

SP-C085 218.2 168.8

SP-C105



Rear I/O View (SP-C085 & SP-C105)




Quick Setup

Installing Hooks


Step 1. Install the mounting brackets into the mounting holes on the four sides of the LCD monitor using 8 x screws (M3x5mm).

_Wall


1 Place the Wall O-ring into the



Step 2. Mount the LCD monitor equipped with 8 brackets onto the wall firmly.




Step 3. Install 8 hooks onto the mounting brackets on the four sides of the LCD monitor to secure firmly.




Installing Wall O-ring

Step 1. Place the Wall O-ring into the groove surrounding the back of the

Step 2. Install the LCD monitor onto the wall



Installing VESA Mount



Accessories

Hook Accessories (option)







x 8

Mounting Brackets M3x5mm screw x 8

Hook x 8

VESA Mount Accessories



VESA Mount Kit x 1

Safety Precaution

The following messages are reminders for safety on how to protect your LCD monitor from damages and extend the life cycle of SP-C085 / SP-C105

1. Check the Cable Voltage

• The range of operating voltage should be DC 12V. Otherwise, the LCD monitor could be damaged.

2. Environmental Conditions

- Place your SP-C085 / SP-C105 on a sturdy, level surface. Be sure to allow enough space to have easy access around the device.
- Avoid extremely hot or cold place to install SP-C085 / SP-C105.
- Avoid exposure to sunlight for a long period of time or in an airtight space.
- Avoid the device from any heating device or using SP-C085 / SP-C105 when it's been left outdoors in a cold winter day.
- Avoid moving SP-C085 / SP-C105 rapidly from a hot place to a cold place and vice versa because condensation may come from inside of the device.

- · Avoid putting heavy objects on top of the device.
- · If water or other liquid spills into this product, unplug the power cord immediately.

4. Good Care

- When the outside of the case is stained, remove the stain with a neutral washing agent with a dry cloth.
- · Never use strong agents such as benzene and thinner to clean the device.
- If heavy stains are present, moisten a cloth with diluted neutral washing agent or with alcohol and then wipe thoroughly with a dry cloth.

[CAUTION!] Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the

• If dust has been accumulated on the outside, remove it by using a special made vacuum cleaner for computers.

manufacturer. Dispose of used batteries according to the manufacturer's instructions. WARNING! Some internal parts of SP-C085 / SP-C105 may have high electrical voltage. And therefore we strongly recommend that qualified

engineers can open and disassemble the device. Please handle LCD and Touchscreen with extra care as they are easily breakable.